

# **Process Control Valves**

U.S. Series 9000 (Includes OR900)

#### **VALVE DESCRIPTION**

The U.S. Series 9000 control valve is an ANSI Class 300 globe-style valve with bolted bonnet and post-guided innervalve. It is available in 1 in. (25 mm), 1-1/2 in. (38 mm) and 2 in. (50 mm) pipe size. The body, bonnet and innervalve are standard in 316SST or optional Alloy C. The standard body, configured in the Flangeless/NPT version, can be installed using NPT fittings or clamped between matching companion flanges. Each size valve is also available with conventional flanges in either the same nominal size as the valve body or oversized flanges that can be adapted to smaller bodies.

Each valve is available with several innervalve sizes, the largest having an integral seat for maximum Cv.

Reduced Cv innervalves fit a threaded body with replaceable seat rings. The unique packing/bonnet design provides high performance and quick easy maintenance when necessary. The Series 9000 control valve is also available with extended bonnets for hot or cold service. Optional double packing, in either PTFE or REK, for fugitive emission control is also available.

The high performance Model 9050 actuator, a multi-spring and diaphragm design, is field reversible from air-to-open to air-to-close without additional parts. The yoke and actuator housings are made of carbon steel and coated with epoxy for corrosion resistance.

Standard material for external hardware is 300 series stainless steel.

The 3...15 psi (0.2...1 bar) spring set is adjustable to 8...20 psi (0.5...1 bar) and the 6...30 psi (0.4...2 bar) spring set is adjustable to 16...40 psi (1...2 bar) to allow a wide range of shutoff capability.

### **Applications**

The Series 9000 control valve is designed for modulating control of liquids and vapors in medium duty industrial applications where performance, quality and small physical size are important. The rugged design offers features and performance levels normally found in more expensive, larger valves.

The unit is designed to handle fluids and environments found in chemical plants, pulp and paper and textile mills, refineries and many other demanding industries.

#### **Valve Materials**

Body	316 stainless steel (CF8M ASTM A351)
Bonnet	316 stainless steel (ASTM A479)
<b>Bonnet Flange</b> 316 stainless steel (CF8M)	
<b>Bolting</b> Gr 5 with Xylan coating	
Gasket Grafoil Gr GTA	
Innervalve 316 stainless steel (ASTM A479)	
Packing	PTFE chevron ring



# **Valve Material Options**

Body	Alloy C (CW-2M ASTM A494)
Bonnet	Alloy C276 barstock
Innervalve Alloy C276, Stellited 316, 316 w/Teflon PFA soft seat	
Packing	Grafoil, Kalrez® (REK)
Bolting	Strain hardened 316 stainless steel

### **ACTUATOR DESCRIPTION**

The Model 9050 actuator is available in either air-to-open/spring-to-close or air-to-close/spring-to-open and is field reversible. It comes with either 3 springs for a 3...15 psi (0.2...1 bar) signal range or 6 springs for a 6...30 psi (0.4...2 bar) signal range. Both ranges are adjustable to match bench loading with the requirements of the application.

#### **Actuator Materials**

Pressure cases	Steel/epoxy
Yoke	Steel/epoxy
Diaphragm	Nitrile/polyester
Springs	17-7PH stainless steel
Diaphragm Plate/Piston	High strength aluminum with hard anodized coating
Hardware	300 stainless steel
Pressure Cases & Yoke	Electroless nickel coating



#### **Actuator Features**

- Designed to ANSI and ISA standards
- Dual body mounting (NPT/Flangeless)
- · Wide range of innervalves
- Linear, Equal Percent or On-Off
- ANSI Class IV seat leak standard
- Encapsulated body gasket
- MoS2 filled nylon stem bushings
- No brass or asbestos
- Epoxy coated steel parts
- · Adjustable spring loading
- Replaceable seats (reduced Cv innervalves only)

## **Actuator Optional Features**

- Stellite innervalve
- · Teflon PFA soft seating
- Class V or VI seat test
- Graphite packing
- Extended bonnets, to 18 in. (457 mm), for hot or cryogenic service.
- Double stuffing box

# **Actuator Design Standards**

	·
Structural	ASME B16.34-1996
Bolting	ASME Section VIII, Appendix 2 and ASME B16.34
Seat leakage	ANSI/FCI 70-2-1991
Cv	ISA- 75.01, 75.02, and 75.11
Face-to-Face (Std)	ISA S75.04
Face-to-Face (Flanged)	ASME B16.10-1992 (Optional F/F dimensions available)
Flange finish	ASME B16.5-1996 (standard is concentric serrations)
Materials	ASTM designations
Code Welding	ASME Section VIII
<b>Accessory Mount</b>	IEC 534 (yoke)

#### **Actuator Accessories**

- Positioner
- i/P positioner
- i/P transducer
- Gauges
- Filter-regulator
- Solenoid
- Limit switches (1 or 2)
- Position transmitter

### **SPECIFICATIONS**

#### **Parts and Material List**

Unless otherwise noted, standard material is 316 SST. (Item numbers refer to items in *Figure 1 on page 3*.)

Idama			Part Numbers	
Item No.	Description	Description 1 in. (DN 25)		2 in. (DN 50)
1a	Body (for replaceable seat)	525966-0001	526149-0001	526151-0001
1b	Body (with integral seat)	525956-0001	526148-0001	526150-0001
2	Bonnet (standard length)	525949-0001	526152-0001	525952-0001
3a	Stem, innervalve	Innervalve pa	rt numbers vary	with Cv and
3b	Innervalve and guide	material. Cons	sult the factory	for complete
3c	Seat (if applicable)	innerva	alve set part nur	nbers.
4	Gasket (Grafoil)	512711-0001	512702-0001	512726-001
5	Packing gland	525950-0001	525950-0001	525950-0001
6	Packing kit (PTFE)	543242-0001	543242-0001	543242-0001
7	Packing adapter	525951-0001	525951-0001	525951-0001
8	Hex screws (Gr 5 Steel)	526119-0001	526119-0003	526119-0004
9	Bonnet flange	512681-0001	512723-0001	512722-0001
10	Yoke locknut	525944-0001	525944-0001	525944-0001

# **Pressure vs Temperature Rating**

neie	Tempe	rature	haum	Notes
psig	°F	°C	barg	Notes
720	100	38	49.6	• Below –20° F (28° C) and above 500° F
620	200	93	42.7	(260° C), use optional SST bonnet studs
560	300	149	38.6	Consult factory for cryogenic service
515	400	204	35.5	Max. temp for TFE packing is 450° F
480	500	260	33.1	(232° C)
450	600	316	31.0	Consider extended bonnets for Grafoils
430	700	371	29.6	packing above 450° F (232° C)
415	800	427	28.6	Consult factory for limits on TFE
395	900	482	27.2	soft seat
365	1000	538	25.1	Consider Stellite for +600° F (315° C) service

Above information taken from ANSI Class 300 pressure vs temperature date for CF8M 316SST. For information or part numbers on other materials, consult the factory.

Detailed actuator and valve assembly drawings are available on request from the factory.

#### **DIMENSIONS**




Figure 1: Dimensions

# **Body Assembly Dimensions**

### For complete valve dimensions, see

"Outline Dimensions For Common Series 9000 Valves" on page 4.

Dim.		5.4 mm)   25)	1-1/2 in. ( (DN	38.1 mm) 40)	2 in. (50.8 mm) (DN 50)		
	in.	mm	in.	in. mm		mm	
Α	4.0	102	4.5	115	4.875	124	
В	1.0	25.4	1.5	38.1	1.75	44.5	
С	3.2	81.3	3.46 87.9		3.59	91.2	
D	2.0	50.8	2.88 73.1		3.625	92.1	
E	1.68	42.7	1.68	42.7	1.68	42.7	
F	1.125	28.6	1.125	28.6	1.125	28.6	




Figure 2: Seat configuration

**Approximate Valve Weight** NPT Body with Size 35 Actuator

Size	lb	kg
1 in. (25.4 mm)	28	12.8
1-1/2 in. (38.1 mm)	31	14.1
2 in. (50.8 mm)	34	15.5

Stroke (All Sizes of M9000): 0.75 in.

### **Innervalve Information**

Valve Size	Orifice Dia. in. (mm)	Orif. area in.² (mm²)	F <sub>L</sub>	Seat Config.	Cv (Linear)	Cv (%)	Max. Oper. ΔP psi (bar)	Max ΔP Shutoff
	1.500 (38.1)	1.77 (1141.9)	0.85	Integr.	25	20	150 (10.3)	300*
2 in.	1.125 (28.6)	1.00 (645.2)	0.86	Repl.	21	17	275 (19.0)	550*
(50.8 mm)	0.812 (20.9)	0.52 (335.5)	0.88	Repl.	15	14	540 (37.2)	720*
	0.625 (15.9)	0.31 (200.0)	0.90	Repl.	7	6.5	660 (45.5)	720
	1.250 (31.8)	1.23 (793.5)	0.85	Integr.	15.5	13	225 (15.5)	450*
1-1/2 in.	0.812 (20.9)	0.52 (335.5)	0.87	Repl.	11	10	540 (37.2)	720*
(38.1 mm)	0.625 (15.9)	0.31 (200.0)	0.90	Repl.	7	6.5	660 (45.5)	720
	0.625 (15.9)	0.31 (200.0)	0.92	Repl.	4	4	660 (45.5)	720
	0.812 (20.9)	0.52 (335.5)	0.85	Integr.	8.3	7.0	540 (37.2)	720*
	0.500 (12.7)	0.20 (129.0)	0.87	Repl.	5.3	4.5	660 (45.5)	720
	0.500 (12.7)	0.20 (129.0)	0.89	Repl.	2	2	660 (45.5)	720
	0.500 (12.7)	0.20 (129.0)	0.91	Repl.	1	1	660 (45.5)	720
1 in. (25.4 mm)	0.156 (4.0)	0.02 (12.9)	0.93	Repl.	0.5	0.5	720 (49.6)	720
(23.4 11111)	0.156 (4.0)	0.02 (12.9)	0.94	Repl.	0.2	0.2	720 (49.6)	720
	0.156 (4.0)	0.02 (12.9)	0.95	Repl.	0.1	0.1	720 (49.6)	720
	0.156 (4.0)	0.02 (12.9)	0.96	Repl.	0.05	0.05	720 (49.6)	720
	0.156 (4.0)	0.02 (12.9)	0.97	Repl.	0.02	N/A	720 (49.6)	720

The largest Cv in each valve size has an integral seat. All other Cv's have replaceable seats.

### **Typical Innervalve Rangeability**


Linear: 50:1

Equal Percent: 60:1

### **NOTES:**

- Pressure drop limits for soft seated trims are 50% of those listed.
- Body recovery coefficient (FsubL) per ISA 75.02-1988 at maximum innervalve opening.
- Shutoff pressures marked with an asterisk (\*) require six (6) actuator springs to obtain required preload.
- Pressures listed under Max. Oper. DeltaP or Max. DeltaP Shutoff relate to the actuator preload requirements and innervalve guide limits. Since fluid and application criteria have a bearing on innervalve performance, some applications may require hardened trim and/or extra preload. In certain applications, the pressures listed may wear or erode the innervalve material.

# **OUTLINE DIMENSIONS FOR COMMON SERIES 9000 VALVES**



			Dimensions						
	Description	1in. (25.4 r	1in. (25.4 mm) DN 25		1-1/2 in. (38.1 mm) DN 40		2 in. (50.8 mm) DN 50		
		in.	mm	in.	mm	in.	mm		
Α	Standard body length (incl. Flangeless/NPT and Socket Weld)	4.00	102	4.50	115	4.875	124		
B1	Centerline of body to yoke mounting point (standard bonnet)	3.20	81	3.46	88	3.59	91		
B2	Centerline of body to yoke mounting point (1" ext. or Dbl. Pack.)	4.20	107	4.46	114	4.59	117		
C1	Centerline of body to top of actuator (standard bonnet)	13.68	348	13.94	348	14.07	358		
C2	Centerline of body to top of actuator (1" ext. or Dbl. Pack.)	14.68	373	14.96	380	15.07	383		
D	Size 35 actuator Diameter	9.81	250	9.81	250	9.81	250		
Е	Size 35 actuator Height	10.48	267	10.48	267	10.48	267		
F1	Flanged body length (with ANSI CL 150 Flanges)	7.25	184	8.75	222	10.00	254		
F2	Flanged body length (with ANSI CL 300 Flanges)	7.75	197	9.25	235	10.50	267		
G	Butt-Weld body length (any pipe schedule. per ISA75.15-1993 Long Pattern)	8.25	210	9.88	251	11.25	286		
H1	Centerline of body to yoke mounting point (10" Cryo bonnet)	10.00	254	10.00	254	10.00	254		
H2	Centerline of body to yoke mounting point (14" Cryo bonnet)	14.00	356	14.00	356	14.00	356		
H3	Centerline of body to yoke mounting point (18" Cryo bonnet)	18.00	521	18.00	457	18.00	457		
J1	Centerline of body to top of actuator (10" Cryo bonnet)	20.50	521	20.50	521	20.50	521		
J2	Centerline of body to top of actuator (14" Cryo bonnet)	24.50	622	24.50	622	24.50	622		
J3	Centerline of body to top of actuator (18" Cryo bonnet)	28.50	724	28.50	724	28.50	724		

Standard Nipple ends are Sch 40, others are available.

Dimensions are subject to change. Detailed engineering drawings of valves and actuators are available from the factory on request.

# **Control. Manage. Optimize.**

Research Control is a registered trademark of Badger Meter, Inc. Other trademarks appearing in this document are the property of their respective entities. Due to continuous research, product improvements and enhancements, Badger Meter reserves the right to change product or system specifications without notice, except to the extent an outstanding contractual obligation exists. © 2021 Badger Meter, Inc. All rights reserved.