PRODUCT SPECIFICATIONS

Model 51i Total Hydrocarbon Analyzer

Flame ionization for the detection of total hydrocarbon

The Thermo Scientific[™] Model 51*i* Total Hydrocarbon (THC)
Analyzer combines proven Flame Ionization Detector (FID) technology, easy to use menu-driven firmware, and advanced diagnostics to offer unsurpassed flexibility and reliability. The Model 51*i* Analyzer is available in low temperature and high temperature versions.



- Flame Ionization Technology (FID) measures organic gases & vapors
- Adjustable ranges
- Real-time correction of THC readings
- Ethernet port and flash memory offer efficient global access

Introduction

The Thermo Scientific Model 51*i*Total Hydrocarbon (THC) Analyzer combines proven Flame Ionization
Detector (FID) technology, easy to use menu-driven firmware, and advanced diagnostics to offer unsurpassed flexibility and reliability. The Model 51*i* Analyzer is available in low temperature and high temperature versions.



The Model 51*i* Analyzer uses a Flame lonization Detector, or FID, to measure organic gases and vapors. FID is a well-known technology that has been used in laboratories and industry for many years. Flame lonization Detectors are highly efficient; providing a wide linear range and sensitive detection of organic compounds.

This state-of-the-art gas analyzer offers features such as an Ethernet port as well as flash memory for increased data storage.

This state-of-the-art gas analyzer also offers features such as an Ethernet port and a flash memory for increased data storage. Ethernet connectivity provides efficient remote access, allowing the user to download measurement information directly from the instrument without having to be on-site.

Easily programmable short-cut keys allow you to jump directly to frequently accessed functions, menus or screens. The larger interface screen can display up to five lines of measurement information while primary screen remains visible.



Thermo Scientific™ Model 51*i* Total Hydrocarbon Analyzer **Thermo Fisher**

thermoscientific

Thermo Scientific Model 51*i* Total Hydrocarbon Analyzer

| Specifications | | | |
|-----------------------|---|--|--|
| Preset ranges | 0-1, 10, 100, 1,000, 5000, and 10000 ppmc | | |
| Custom ranges | 0-1 to 10000 ppmc | | |
| Zero noise | 0.025 ppmc RMS (10 second averaging time) | | |
| Minimum detectable | 0.050 ppm (10 second averaging time) | | |
| Zero drift (24 hour) | < 0.50 ppm | | |
| Span drift (24 hour) | < 2% of range or 0.20 ppm (whichever is larger) | | |
| Response time (90%) | 15 seconds at 1 second averaging time | | |
| Precision | 2.0% of reading or 0.1 ppm (whichever is larger) | | |
| Linerarity | +/-2.0% of span (at concentrations of 10% to 150% of span) | | |
| Sample flow rate | 0.75 to 1.50 lpm nominal | | |
| Makeup air flow rate | 150 ccm to 300 ccm hydrocarbon free air | | |
| Fuel flow rate | 10 to 35 ccm hydrogen or 50 to 120 ccm H2/He mixture | | |
| Operating temperature | 59°-95°F (15°- 35°C), safely operated 32°-113° F (0°-45° C) | | |
| Power requirements | 100 VAC, 115 VAC, 220-240 VAC +/-10%, 50/60Hz, 420W | | |
| Size and weight | 16.75" (W) × 8.62" (H) × 23" (D), 50 lbs. (22.7 kg) | | |
| Outputs | Selectable voltage, RS232/RS485, TCP/IP, 10 status relays, and power fail indication (standard). 0-20 or 4-20 mA isolated current output (optional) | | |
| Inputs | 16 Digital Inputs (standard), 8 0-10 Vdc Analog Inputs (optional) | | |

To maintain optimal product performance, you need immediate access to experts worldwide, as well as priority status when your air quality equipment needs repair or replacement. We offer comprehensive, flexible support solutions for all phases of the product life cycle. Through predictable, fixed-cost pricing, our services help protect the return on investment and total cost of ownership of your Thermo Scientific products.

USA

27 Forge Parkway Franklin, MA 02038 Ph: (508) 520-0430 Fax: (508) 520-2800 orders.aqi@thermofisher.com

China

+Units 702-715, 7th Floor Tower West, Yonghe Beijing, China 100007 Ph: +86 10 84193588 info.eid.china@thermofisher.com

India

C/327, TTC Industrial Area MIDC Pawane New Mumbai 400 705. India Ph: +91 22 4157 8800 india@thermofisher.com

Europe

Ion Path, Road Three, Winsford, Cheshire CW73GA UK Ph: +44 1606 548700 Fax: +44 1606 548711 sales.epm.uk@thermofisher.com

Ordering information

Model 51i-HT Total Hydrocarbon Analyzer Choose from the following configurations/options to customize your own Model 51i-HT Analyzer 1. Voltage options A = 120 VAC 50/60 Hz (standard) B = 220 VAC 50/60 Hz J = 100 VAC 50/60 Hz 2. Internal zero/span M = No internal zero/span, mixed fuel N = No internal zero/span, hydrogen fuel Y = Internal zero/span, mixed fuel Z = Internal zero/span, hydrogen fuel 3. Optional I/O A = None (standard) C = I/O expansion board (4-20mA outputs – 6 channels, 0-10v inputs - 8 channels) 4. Mounting hardware A = Bench mounting and ears/handles, EIA Your Order Code: Model 51i -HT

Model 51i-LT Total Hydrocarbon Analyzer

Choose from the following configurations/options to customize your own Model 51i-LT Analyzer

1. Voltage options

A = 120 VAC 50/60 Hz (standard)

B = 220 VAC 50/60 Hz

J = 100 VAC 50/60 Hz

2. Internal zero/span

N = No internal zero/span, hydrogen fuel

Z = Internal zero/span, hydrogen fuel

3. Optional I/O

A = None (standard)

C = I/O expansion board (4-20mA outputs - 6 channels, 0-10v inputs - 8 channels)

4. Mounting hardware

A = Bench mounting and ears/handles, EIA

Your Order Code: Model 51i -LT

| 1 1 | | |
|-----|--|--|
| | | |
| | | |



